

Conserve101:

Powerful Lessons from your Electric Cooperative

Steps to Adjust Water Heater Thermostat:

Step 1: Flip the breaker to turn off power to the water heater.

Step 2: Remove the two thermostat covers that are located on the front of the water heater.



Step 3: Remove the insulation that is behind the covers to see the thermostat.



Step 4: Using a flat head screwdriver, turn the rotating dial to the desired temperature, 120° F. Do this on bottom thermostats.



Step 5: Carefully, put the insulation back over both thermostats.

Step 6: Place the thermostat covers back over both of the thermostats.

Step 7: Flip the breaker to turn the water heater back on.



Touchstone Energy® Cooperatives of Alabama & Florida